



CONCO PAINTS

Pro Technology... Engineered For The Job™

Product Data Sheet

9720 PROTEX™ SMOOTH TEXTURE INTERIOR LATEX WALL & CEILING PAINT

PROTEX™ SMOOTH TEXTURE INTERIOR LATEX WALL & CEILING PAINT allows the creation of a decorative textured surface while hiding minor surface imperfections. This ready-mix texture coating can be applied, using a variety of tools, to properly prepared interior surfaces such as plaster, wallboard, wood, masonry and metal.

Recommended Uses

- Walls & Ceilings
- Commercial & Residential Property
- Drywall, Wood, Concrete, Plaster, Masonry, and Primed Metal
- Interior Application

Performance Benefits

- Orange Peel, Knockdown, and Splatter Finishes
- Hides Minor Surface Imperfections
- Roll or Spray Application

Recommended Systems

New Wallboard or Drywall

- 1 coat Conco® P001 Drywall P.V.A. Primer / Sealer
- 1 coat ProTex™ 9720 Smooth Texture Interior Latex Wall & Ceiling Paint

Wood

- 1 coat Conco® P001 Drywall P.V.A. Primer / Sealer
- 1 coat ProTex™ 9720 Smooth Texture Interior Latex Wall & Ceiling Paint

Plaster

- 1 coat Conco® P001 Drywall P.V.A. Primer / Sealer
- 1 coat ProTex™ 9720 Smooth Texture Interior Latex Wall & Ceiling Paint

Masonry

- 1 coat Conco® P001 Drywall P.V.A. Primer / Sealer
- 1 coat ProTex™ 9720 Smooth Texture Interior Latex Wall & Ceiling Paint

Aggregate Block

- 1 coat Conco® P9511 Acrylic Latex Block Filler
- 1 coat ProTex™ 9720 Smooth Texture Interior Latex Wall & Ceiling Paint

Metal

- 1 coat Conco® P801 DTM Acrylic Prime & Finish
- 1 coat ProTex™ 9720 Smooth Texture Interior Latex Wall & Ceiling Paint

Note: Topcoating is recommended for wall surfaces and is optional for ceilings. Topcoat with any Conco® Interior Latex Paint.

Technical Information

| | |
|--|--|
| Finish: | Flat |
| Colors: | White |
| Drying Time (@ 77°F, 50% Rel. Humidity) | |
| To Touch: | 2-4 Hours |
| To Topcoat: | 4-6 Hours |
| Spread Rate: | 35-75 Sq. Ft. /Gal (dependant upon surface texture, porosity, and application method) |
| Film Thickness: | 20.0 mils wet 7.8 mils dry |
| Volume Solids: | 39% ± 2% |
| Weight Solids: | 69% ± 2% |
| Weight per Gallon: | 12.5 lbs |
| Vehicle Type: | Acrylic |
| Flash Point: | Not Applicable |
| V.O.C. Level: | 0 g/L; 0.00 lb/gal |
| Reduction: | Water |
| Cleanup: | Soap and Water |
| Size: | Available in Twos and Fives |

Warranty:

If this product, when applied according to label instructions, fails to perform to your complete satisfaction, we will either replace an equivalent quantity of product free of charge or refund the purchase price, upon presentation of proof of purchase. This warranty does not include labor or costs associated with labor for the application of any product. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Surface Preparation

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Preparation

To ensure proper adhesion, all surfaces must be clean, dry and free from dirt, wax, grease, oil, chalk, mildew and loose or peeling paint. Nail holes, cracks and other surface imperfections should be properly filled, sanded smooth and dusted clean. All mildew and mold must be completely and thoroughly removed. Glossy surfaces must be sanded and dusted clean. Always wear a properly selected and fitted NIOSH/MSHA approved dust mask or respirator when sanding.

New Wallboard or Drywall: Fill cracks and holes with spackling compound and sand smooth. Joint compound must be cured and sanded smooth. Remove all sanding dust.

Wood: Sand any exposed wood to a fresh surface. Patch all holes and imperfections with wood filler or putty and sand smooth. Remove all sanding dust.

Plaster: (allow to cure for 30 days): Must be dry, cured and hard with a pH < 9.5. Treat textured, soft, porous or powdery plaster with a solution of 1 pint of vinegar to 1 gallon of water. Repeat until surface is hard, rinse with clear water and allow to dry.

Masonry/Aggregate Block (allow to cure for 30 days): Remove all surface contamination and dust by washing with an appropriate cleaner and allow to dry.

Metal: Remove all contaminants and rust. Wipe clean using an appropriate cleaner.

Not recommended over wallpaper.

Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

Cleanup Information

Clean hands and tools immediately after use with warm soapy water. Any overspray or spatters on other surfaces should be cleaned immediately with warm soapy water and rinsed.



CONCO PAINTS
Pro Technology... Engineered For The Job™

9720

PROTEX™ SMOOTH TEXTURE INTERIOR LATEX WALL & CEILING PAINT

Application

Do not apply at air, surface or product temperatures below 50°F or above 90°F.

Hopper Gun: To achieve an **orange peel effect**, spray apply smooth texture paint in an even pattern using a small sized orifice and very high air pressure. For a **splatter effect**, use a large sized orifice and reduced air pressure. The **knockdown effect** may be achieved by applying the splatter application and then wiping down the wet texture with a clean, damp trowel.

May be thinned with up to ½ cup of water per gallon for spray application.

Roller

Apply smooth texture paint with a 3/8" nap synthetic roller in 3' x 3' sections at a time, leaving a wet edge in which to blend the next section. Decorate the wet texture material by stippling with a brush, loop roller, sponge or other decorative tools.

Tips for Better Performance

- Stir well before using
- Clean the surface thoroughly
- Prepare the substrate to create a uniform surface
- Patch cracks, crevices and through-substrate openings using proper sealant or patch
- Caulk as needed using quality latex or siliconized latex caulk or sealant

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Conco Paints. Information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Conco Paint retailer or sales representative to obtain the most recent Product Data Sheet.